

Fogging Device Instructions

For use with AP-439

Preparation

Organise PPE

- Gloves
- Goggles
- Gown or Plastic Apron
- Mist Mask

Wearing Gloves & Goggles, make up a chemical solution suitable to your requirements with the below dilutions:

SARS-Cov-2 Treatment, Outbreaks or High Risk:

Add 64ml AP-439 per litre of clean water (1:16)

Bacterial Disinfection/Decontamination:

Add 32ml AP-439 per litre of clean water (1:32)

General Disinfection, Odour Control:

Add 20ml AP-439 per litre of clean water, 1:50)

Add solution to Fogging Device tank, depending on area to be sanitised.

(1 litre of solution will cover approximately 230 square metres).

Prepare Area to be fogged

Before entering the room, ensure full PPE is worn. Remove any items from the room which may be damaged by moisture, such as paper or tissue.



Fogging Device Instructions

For use with Percide



Fogging of Area

Close the door while fogging to prevent fog migrating to other rooms and areas.

Adjust droplet size by turning nozzle. Turn to left for smaller droplet size, right for a larger droplet size. Surface should stay wet for recommended contact time.

Fog all surfaces.

Start in the area of the room that is the furthest from the exit door and fog from top to bottom, working back towards the exit door.

Exit room immediately after fogging and close the door after exiting the room.

Remove PPE and wash hands thoroughly.



Re-Entry of Area

Wait 15 minutes before re-entering the room.

Wipe any surfaces that are still damp with a paper towel or clean cloth.

